#### Features

- Light integrated vision sensor
- Minimized image distortion with global shutter method
- Proprietary technology to block optical interference to improve optical performance (patent)
- Stronger in environment of vibration or impact with lens cover detachment prevention technology
- Various inspection function
  - : Alignment, brightness, contrast, area, edge, shape comparison, length, angle, diameter, object counting, color identification, area of color, object of color counting
- Inspection test with simulator
- Flexible response to changing work environment by setting 32 work groups (64 inspection items for each work group)
- Saving data to FTP server
- Free vision sensor program (Vision Master)
  - : Inspection simulator, managing parameter and work group, monitoring inspection result, inspection result FTP transmission, multilingual support, Etc.
- Protection structure IP67 (IEC standard)










#### Manual

For the detail information and instructions, please refer to user manual, and be sure to follow cautions written in the technical description (catalog, homepage).

Visit our homepage (www.autonics.com) to download manuals.


# Ordering Information



×1: Light can be purchased separately.

D-2 Autonics

# **■** Overall Configuration Diagram



(A) Photoelectric Sensors

(B) Fiber Optic Sensors

(C) Door/Area Sensors

(D) Vision Sensor

(E) Proximity Sensors

(H) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets

(J) SSRs / Power Controllers

(K) Counters

(N) Tacho / Speed / Pulse Meters

(Q) Switching Mode Power Supplies

(R) Stepper Motors & Drivers & Controllers

(S) Graphic/ Logic Panels

(T) Field Network Devices

**Autonics** 

# **VG Series**

## Accessories

- Assembly tool
- ASST-VG



- O Bracket A
- BK-VG-A



# Sold Separately

- Clight
- LR-W-06-VG (white)
- LR-R-06-VG (red)
- LR-G-06-VG (green)
- LR-B-06-VG (blue)



- O Bracket B
- BK-VG-B



- Protection cover
- P96-M12-1



 $\ensuremath{\ensuremath{\bowtie}}$  Protection cover protects the unused connector from foreign object. When installing, hand tighten.

- O Color filter
- FL-R-VG (red)



● FL-G-VG (greed)



● FL-B-VG (blue)







- O Polarizing filter
- FL-P-VG (window) FL-RP-VG (red)
- FL-GP-VG (green) FL-BP-VG (blue)

• FL-ICP-VG (infrared blocking)










- O Power I/O cable
- Standard CID-2-VG (2m) CID-5-VG (5m) CID-10-VG (10m)
- L type CLD-2-VG (2m) CLD-5-VG (5m) CLD-10-VG (10m)



CIR-2-VG (2m) CIR-5-VG (5m) CIR-10-VG (10m)











D-4**Autonics** 

# **■** Specifications

Мо	del	VG-M04□-8E	VG-M04□-16E	VG-M04□-25E	VG-C04□-8E	VG-C04□-16E	VG-C04□-25E		
Effective focal length		8mm	16mm	25mm	8mm	16mm	25mm		
Min	. working distance	50mm	100mm	200mm	50mm	100mm	200mm		
Pov	wer supply	24VDC== (±10%)							
Cur	rrent consumption	1A							
Inspection	Inspection item	Alignment, brightr shape comparisor object counting			shape comparison object counting*	Alignment, brightness*2, contrast*2, area*2, edge, shape comparison*2, length, angle, diameter, object counting*2, color identification, area of color, object of color counting			
spec	Work group	32					'		
프	Simultaneous inspection	64					'		
	Camera frame per second <sup>*1</sup>	Max. 60fps							
	Image filter	Preprocessing, ex	ternal filter (color	filter, polarizing filt	er)				
Ω	Image element	1/3 inch mono CM	108		1/3 inch color CN	MOS			
snap	Resolution	752×480 pixel							
mage	Camera frame per second <sup>*1</sup>	Max. 60fps							
=	Shutter	Global shutter							
	Exposure time	20 to 10,000μs							
ight	ON/OFF method	Pulse							
Lig	Color	White, red, green,	blue						
Trig	gger mode	External trigger, internal trigger, free-run trigger							
ă	Signal	Rated input 24VDC (±10%)							
Input	Туре	External trigger (T	RIG), work group	change (IN0 to IN	3), alarm cleared (	IN0 to IN3), encod	ler (IN2, IN3)		
	Signal	NPN or PNP open collector output Max. 24VDC== 50mA, residual voltage: max. 1.2VDC==							
Output	Туре	Control output (OUT0 to OUT3) : inspection completion, inspection result, external light trigger, alarm, camera busy, changing work group completed							
	FTP transmission	Possible							
Cor	mmunication	Ethernet (TCP/IP)	, 100BASE-TX/10	BASE-T					
Pro	tection circuit	Output short over current protection circuit							
Ind	icator		n indicator (DATA		cator (LINK), pass	indicator (PASS): (	green LED		
Ins	ulation resistance	Over 20MΩ (at 500VDC megger)							
Die	lectric strength	500VAC 50/60Hz for 1 min							
Vib	ration	1.5mm amplitude at frequency of 10 to 55Hz (for 1 min) in each X, Y, Z direction for 2 hours							
Sho	ock	300m/s² (approx. 30G) in each X, Y, Z direction for 3 times							
Enν	viron Ambient temp.	0 to 45°C, storage	e: -20 to 70°C						
me	nt Ambient humi.	35 to 85%RH, sto	rage: 35 to 85%R	Н					
Pro	tection structure	IP67 (IEC standard)							
Material Case: aluminum, lens cover/focus adjuster: polycarbonate, cable: poly					ate, cable: polyure	thane			
Acc	cessories	Assembly tool, bracket A, mounting screw: 2							
Sol	d separately	Light, color filter, p	oolarizing filter, po	wer I/O cable, Eth	ernet cable, bracke	et B, protection cov	/er		
App	oroval	C€ №							
		Approx. 415g	Approx. 416g	Approx. 416g	Approx. 415g	Approx. 416g	Approx. 416g		

※1: The number of camera frames per second can be different by image setting or inspection item.

(B) Fiber Optic Sensors (C) Door/Area Sensors (D) Vision Sensor (E) Proximity Sensors (H) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets (J) SSRs / Power Controllers (K) Counters (N) Tacho / Speed / Pulse Meters (O) Display Units (Q) Switching Mode Power Supplies (R) Stepper Motors & Drivers & Controllers (S) Graphic/ Logic Panels (T) Field Network Devices


(A) Photoelectric Sensors

<sup>\*2:</sup> These inspection items convert a color image to a mono color image to inspect data.

<sup>※3:</sup> The weight includes packaging. The weight in parenthesis is for unit only.

<sup>\*</sup>Environment resistance is rated at no freezing or condensation.

## Connections



\*Use the product which of power supply is 24VDC.

When selecting a product, please refer to Autonics selection guide.

## O Power I/O cable (M12 12-pin connector)

	•			•					
Pin arrangement	Pin No.	Cable color	Signal	Function					
	1	Brown	24VDC	24VDC					
	2	Blue	GND	GND					
	3	White	TRIG	Trigger input					
	4	Green	IN0	Work group change Bit 0	Work group change Clock				
	5	Pink	IN1	Work group change Bit 1	Work group change Data				
9 10 3 8 12 11 4	6	Yellow	IN2	Work group change Bit 2	Encoder - Up counter - Quadrature A	Alarm cleared			
765	8	Gray	IN3	Work group change Bit 3	Encoder - Down counter - Quadrature B				
	11	Gray/Pink	COMMON	COMMON					
	7	Black	OUT0						
	9	Red	OUT1	Inspection completion	n, inspection result, ex	ternal light trigger,			
	10	Purple	OUT2	alarm, camera busy,	changing work group	completed			
	12	Red/Blue	OUT3						


# ○ Ethernet cable (M12 8-pin/RJ45 connector)

Pin arrangement	M12 8-pin		Cable color	RJ45		
Fill alrangement	Pin No.	Signal	Cable Color	Pin No.	Signal	
	6	RX+	White/Orange	1	TX+	
	4	RX-	Orange	2	TX-	
	5	TX+	White/Green	3	RX+	
3 8 9	8	TX-	Green	6	RX-	
	1	_	White/Blue	5	_	
4 5 6	7	_	Blue	4	_	
	2	_	White/Brown	7	_	
	3	_	Brown	8	_	


D-6 Autonics

# **■** Input Circuit Diagram

External trigger input (TRIG)
 Work group change input (IN0 to IN3)
 Alarm cleared input (IN0 to IN3)




#### Encoder input (IN2, IN3)




# ■ Control Output Circuit Diagram


#### NPN open collector output



#### PNP open collector output



## Unit Description



- ① Lens cover: Front cover of lens
- XIn case using a filter (color filter/polarizing filter), separate the lens cover with the assembly tool before insert the filter.
- ② Lens: There are 8mm, 16mm, 25mm models by effective focal length.
- 3 Light cover: Light cover fixes inner LED lights.
- Light: Inner LED lights
  - XIn order to change the light, separate lens cover and light cover.
- ⑤ Bracket mounting hole on back side: Install the vision master from the back side using bracket B.
- ① Ethernet connector: Connect the Ethernet cable. It is for TCP/IP communication.
- ® Focus adjuster: After fixing vision sensor, adjust focus by the rotating focus adjuster.
- 9 Indicators

Indicators	Indicators		Descriptions		
POWER	Power indicator	Green LED	Turns ON when power is supplied.		
LINK	Ethernet connection indicator	Green LED	Turns ON when vision sensor is connected with PC (Ethernet communication).		
DATA	Data transmission indicator	Orange LED	Flashes when data is transmitted from vision sensor to PC.		
FAIL	Failure indicator	Red LED	Flashes when detects failure during work group inspection.		
PASS	Pass indicator	Green LED	Flashes when passed inspection during work group inspection.		

(A) Photoelectric Sensors

(B) Fiber Optic Sensors

(C) Door/Area Sensors

(D) Vision Sensor

(E) Proximity Sensors

Sensors

Pressure Sensors

(G) Rotary Encoders

(H) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets

(I) Temperature Controllers

(J) SSRs / Power Controllers

> () ounters

(L) Timers

(M) Panel Meters

(N) Tacho / Speed / Pulse Meters

(O) Display Units

> P) Sensor Controllers

(Q) Switching Mode Power Supplies


(R) Stepper Motors & Drivers & Controllers

(S) Graphic/ Logic Panels

(T) Field Network Devices

(U) Software


Dimensions



(unit: mm)


# Accessory

#### Bracket A (BK-VG-A)




## Sold separately


#### Bracket B (BK-VG-B)



2-M4


#### ● Power I/O cable (M12 12-pin connector)





Type	Model	L
	CID-2-VG	2m
Standard	CID-5-VG	5m
	CID-10-VG	10m
	CLD-2-VG	2m
L type	CLD-5-VG	5m
	CLD-10-VG	10m

## ● Ethernet cable (M12 8-pin/RJ45 connector)



Туре	Model	L
	CIR-2-VG	2m
Standard	CIR-5-VG	5m
	CIR-10-VG	10m
	CLR-2-VG	2m
L type	CLR-5-VG	5m
	CLR-10-VG	10m

# Installation

#### Installing vision sensor

- Checking working distance and FOV by effective focal length
- Bracket installation (fixing vision sensor)

#### Installing software

 Installing the vision sensor program, Vision Master, to PC

# Connecting vision sensor and PC

 Setting network from Vision Master

#### Adjusting vision sensor focus


Running Vision Master and activating the 'Focusing Guide' function in the camera setting menu

- Adjusting focus with focus adjuster


#### O Bracket installation

Install horizontally from the bottom


- bracket A (accessory)



Install vertically from the bottom
 bracket B (sold separately)




Install vertically from the back side
 bracket B (sold separately)



## Installation position


Place the sensing target at the center of the vision sensor lens.



# O Focus adjustment

After installing and running Vision Master, use the focusing guide function to adjust the focus.

Using (-) screwdriver, turn focus adjuster to right and left to adjust the focus.



(A) Photoelectric Sensors

(B) Fiber Optic Sensors

> (C) Door/Area Sensors

(D) Vision Sensor

(E) Proximity Sensors

(F) Pressure Sensors

(G) Rotary Encoders

(H) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets

(I) Temperature Controllers

(J) SSRs / Power Controllers

(K) Counters

(L) Timers

> anel leters

(N) Tacho / Speed / Pulse Meters

(O) Display Units

> P) Sensor Controllers

(Q) Switching Mode Power Supplies

(R) Stepper Motors & Drivers & Controllers


(S) Graphic/ Logic Panels

(T) Field Network Devices

(U) Software


# **■** Working Distance and FOV by Effective Focal Length

# Working distance



Effective focal length (f)	8mm	16mm	25mm
Min. working distance	50mm	100mm	200mm
Brightness	F2.0	F2.5	F2.5

# O FOV (Field of view)



#### Sensing range by effective focal length (unit: mm)

Effective focal length	Working distance	50	100	200	300	400	500	600	700	800	900	1,000
	FOV	16	32	64	96	129	161	193	255	257	289	322
8mm	Horizontal axis (H)	27	54	108	163	217	271	325	380	434	488	542
	Vertical axis (V)	17	35	69	104	138	173	208	242	277	311	346
	FOV	_	16	33	49	66	82	99	155	132	148	165
16mm	Horizontal axis (H)	_	28	56	83	111	139	167	195	222	250	278
	Vertical axis (V)	_	18	35	53	71	89	106	124	142	160	177
	FOV	_	_	23	34	46	57	68	80	91	103	114
25mm	Horizontal axis (H)	_	_	38	58	77	96	115	134	154	173	192
	Vertical axis (V)	_	_	25	37	49	61	74	86	98	110	123

D-10 Autonics

# ■ Vision Sensor Program [Vision Master]

Vision Master is the vision sensor program that allows setting of vision sensor parameters and management of monitoring data such as inspection status and status information.

#### <Computer specification for using software>

	company opening comment
Item	Minimum specifications
System	32bit (×86) or 64bit (×64) processor over 1GHz
Operations	Microsoft Windows 7/8/10
Memory	1GB+
Hard disk	400MB+ of available hard disk space
VGA	Resolution: 1024×768 or higher
Others	RJ45 Ethemet port

#### <Vision Master execution screen>



 $\ensuremath{\mathbb{X}}\xspace$  Vision sensor is connected with Vision Master in Ethernet (TCP/IP) communication.

\*\*For initial IP address of vision sensor, refer to the following table. Configure the network settings of vision sensor via Vision Master.

IP address	192.168.0.2
Subnet mask	255.255.255.0
Gateway	192.168.0.1

#### <Inspection setting screen>




#### <Inspection executing screen>






#### <FTP transmission setting screen>



## <Registered inspections in work group>



#### <Inspection status monitoring screen>

Inspecti	on Status					Reset S	tatistics
Number	Work Name	Result Value	Result	Pass/Fail	Operating Time(ms)	- Input Trigger	2.3%
1	Alignment 1	82 [X:377 Y:250 R:0.2]	0	103/0(100.0%)	562.72	Pass	103
2	Brightness 1	153	0	78/25(75.7%)	0.19	Fail	4352
3	Contrast 1	69	<b>(2)</b>	87/16(84.4%)	1.02	- Work	46.6%
4	Area 1	5179	0	87/16(84.4%)	0.37	All Pass	48
5	Edge 1	0 [Distance:8]	<b>(2)</b>	94/9(91.2%)	9.63	One or More Failure	55
6	Length 1	0	0	89/14(86.4%)	0.82	The Number of Works	9
7	Angle 1	100	0	100/3(97.0%)	23.00	Overall Inspection Time(ms)	728
8	Diameter 1	68 [Round:88]	0	100/3(97.0%)	86.24	¥	
				817/110(88.1%)	694.26		

(A) Photoelectric Sensors

(B) Fiber Optic Sensors

> (C) Door/Area Sensors

(D) Vision Sensor

(E) Proximity Sensors

> F) Pressure

(G) Rotary Encoders

(H) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets

(I) Temperature

(J) SSRs / Power Controllers

> (K) Counters

> > .) mers

(M) Panel Meters

(N) Tacho / Speed / Pulse Meters

(O) Display Units

> (P) Sensor

(Q) Switching Mode Power Supplies

(R) Stepper Motors & Drivers & Controllers


(S) Graphic/ Logic Panels

(T) Field Network Devices


(U) Software

#### O Vision Master Work Flow

Setting mode



#### Operation mode



(A) Photoelectric Sensors

(B) Fiber Optic Sensors

> (C) Door/Area Sensors

(D) Vision Sensor

(E) Proximity Sensors

(F) Pressure Sensors

Sensors

(G) Rotary Encoders

(H) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets

(I) Temperature Controllers

(J) SSRs / Power Controllers

(K) Counters

(L) Timers

> M) Panel Veters

(N) Tacho / Speed / Pulse Meters

(O) Display Units

> (P) Sensor

(Q) Switching Mode Power Supplies


(R) Stepper Motors & Drivers & Controllers

(S) Graphic/ Logic Panels


(T) Field Network Devices

(U) Software

## Inspection function




**Autonics** 



<sup>\*\*</sup>These examples include position alignment. (except area, diameter, color identification, area of color, and object of color counting inspection)
\*\*Color identification, area of color, and object of color counting are only for VG-C Series.

## Inspection function



\*\*These examples include position alignment. (except area, diameter, color identification, area of color, and object of color counting inspection)

Color identification, area of color, and object of color counting are only for VG-C Series.

## Proper Usage


## O Cautions during Use

- Follow instructions in Cautions during Use. Otherwise, it may cause unexpected accidents.
- 24VDC power supply should be insulated and limited voltage/current or Class 2, SELV power supply device.
- In order to avoid malfunction from static electricity or noise, ground shield wire of the power I/O cable.
- Do not disconnect the power supply while setting operation or saving set information.
   It may cause data loss.
- Do not disconnect the power supply while updating firmware. It may cause product damage.
- Keep optical section of the sensor away from the contact with water, dust and oil.
   It may cause malfunction.
- When changing the light or filter, use the assembly tool and observe installation instruction.
- When the sensor is not used for a long time, separate the power cable and to store.
- When connecting network, connection must be operated by technical expert.
- In the following case, disconnect the power supply immediately. It may cause fire or product damage.
  - ① When water or foreign substance is detected in the product
  - ② When the product is dropped or case is damaged
  - 3 When smoke or smell is detected from the product
- Do not use the product in the place where strong magnetic field or electric noise is generated.
- This unit may be used in the following environments.
- ① Indoor (in the environment conditions in specifications)
- ② Altitude max. 2,000m
- 3 Pollution degree 2
- ④ Installation category II

D-16 Autonics

# **Applications**

# Applications



(A) Photoelectric Sensors

(B) Fiber Optic Sensors

> (C) Door/Area Sensors

(D) Vision Sensor

(E) Proximity Sensors

> (F) Pressure Sensors

(G) Rotary

(H) Connectors/ Connector Cables Sensor Distributio

(I) Temperature Controllers

(J) SSRs / Power Controllers

(K) Counters

> L) Timers

(M) Panel Meters

(N) Tacho / Speed / Pulse

O) Display Jnits

P) Sensor

(Q) Switching Mode Power Supplies

(R) Stepper Motors & Drivers & Controllers


(S) Graphic/ Logic Panels

(T) Field Network Devices

(U) Software

# **Applications**

# Applications




D-18 Autonics

# **Technical Description**

# Vision Sensor Overview

Vision sensor takes a picture of the sensing target and distinguishes features through image processing to output data or inspection result.





#### • Human and vision sensor

- Haman and Violon Concor						
Item	Human	Vision sensor				
Acquirect	Subjective data according to a worker	Objective data by constant input				
Accuracy (error)	Possibility of error occurrence according to worker's condition	Upgrading function and accuracy by system update				
Continuity	Worker shift according to working time	Continuous work				
Rapidity	Slower inspection speed due to limited inspection and distinction	Faster inspection speed according to the system configuration				
Proficiency	Requiring worker's proficiency (training time)	Directly usable right after installing the system				
Cost	A steady increase of personnel expenses	No additional cost after initial installation				
Output	No output function, direct inspection and result input by workers	Various output with communication				

#### Photoelectric sensor and vision sensor

A vision sensor can replace multiple photoelectric sensor and can be connected with another device to set various input/output options.

Item	Photoelectric sensor	Vision sensor
Performance	Low	High
Setting	Simple	Flexibly settable with communication setting according to environment
Main application (inspection)	Simple sensing of presence	Sensing target object with various inspection function (alignment, brightness, contrast, area, edge, length, angle, diameter, object counting)

# Use of Light and Filter


#### Light

In order to get an image of stable quality, it is important to select the proper light for material, shape and gloss of the sensing target and brightness of the place.



#### Octoor Color Co






#### O Infrared cut-off filter

Without infrared cut-off filter	With infrared cut-off filter
→ Focused on the heater	→ Focused on the safety net

#### O Polarizing filter: cutting diffuse reflection



(A) Photoelectric Sensors

(B) Fiber Optic Sensors

(C) Door/Area Sensors

(D) Vision Sensor

(E) Proximity Sensors

> (F) Pressure

(G) Rotary

(H) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets

> (I) Temperature Controllers

(J) SSRs / Power Controllers

(K) Counters

> (L) Timers

(M) Panel Meters

(N) Tacho / Speed / Pulse Meters

(O) Display Units

P) Sensor

(Q) Switching Mode Power Supplies

(R) Stepper Motors & Drivers & Controllers

(S) Graphic/ Logic Panels

(T) Field Network Devices

(U) Software


# **Technical Description**

## Glossary

## O Pixel

An image is made up of the square dots which are not divided, and the square dots, the smallest unit of an image, is called 'Pixel'.

The more pixels the image has, the more precise and detailed the image is.










High number of pixels

Median number of pixels


Low number of pixels

#### Shutter function

Shutter is the entrance of light to enter into the camera, and controls exposure with opening/closing time.



This method captures an images by scanning screen horizontally or vertically. Since the exposure timing of the sensor is different, image distortion can occur.




This method captures the whole part of an image at the same time. When taking pictures of fast moving object, this method helps take pictures without image distortion.

## CMOS (Complementary Metal Oxide Semiconductor) image sensor

Measurement method	Acquires an image by converting the signal of each pixel	
Features	<ul> <li>Low power consumption</li> <li>Stronger to impact or vibration</li> <li>Faster by Individual A/D conversion</li> <li>Minimized interference with operation by pixel</li> <li>Economical price</li> </ul>	
Application	Object recognition, distance measurement, ultrafast camera shooting	

#### FOV (Field of View)

FOV is the size of the area that can be inspected at one time, and it is the area that vision sensor can see. Depending on the effective focal length, working distance and sensing range are different.



## O ROI (Region of Interest)

ROI is the area of interest to inspect in the image captured by the camera.



D-20 Autonics